

Fleet Hawks ELD App

User Manual






Table of Contents

1 Login	3
2 Vehicle Profile	4
3 Select Tractor	5
4 Add New Tractor	6
5 Add VIN Number	7
6 ECM-Linked Devices	8
7 Diagnostic	9
8 HOS (Hours of Service)	10
8.1 HOS Change Duty Status	11
9 Warning Popup While Change The Duty Status	12
10 Remarks For On Duty	13
10.1 Remarks For On Duty Cross Border	14
11 Enter Location	15
12 Inspection Reports List Page	16
13 New Vehicle Inspection	17
14 Enter Remarks	18
14.1 Detail Remarks	19
15 Add e-Sign, Take A Picture and Upload inspection	20
16 Signature List	21
17 Draw e-Signature	22
18 Save & Finish	
19 Open Logbook	
20 Logbook Graph	25
21 Logs Detail	26
22 Edit, Delete Logs	27
23 Add New Logs	28
24 Violations	29
25 Driver Profile	30
26 Rule Set	31
27 Annotations	
28 Certification	
29 Certify Records	34
30 Go To Co-Driver Login	35
31 Co-Driver Login	36
32 HOS of Co-Driver	37
33 Shipment	38
34 DOT Inspection	39
35 Export ELD Data Option	40
36 Non-ECM Compliance Compatibility	41




00:11 🗟 🖪 🐍 •	©च 🚨 🕸 🗣 🛜	.ıl ╬ .ıl 79% =
Fleet Hawks ELD Login Page		
Username		
Password		
English		▼
Login		



After Login Vehicle Profile Page

Select Tractor or Select Trailer





Select Tractor


- → Type in the search bar and select the tractor from list
- → Press plus icon to add new tractor





Add New Tractor


→ First three fields are mandatory





Add New Tractor

→ VIN number needs to be valid as per the vehicle else it won't send ELD data to FMCSA






ECM-Linked Devices





Diagnostic


→ Run ELD diagnostic for vehicle information if you press continue it will take to the HOS home page





HOS (Hours of Service)


→ Select the duty status and it will automatically update your driven time, on shift and on cycle





HOS (Hours of Service)


→ To change the duty status you should press any of the following button





Warning popup will apear while changing the duty status


→ For eg. when you press ON duty it will ask for a warning message





Remark for On Duty


→ Select remarks and then press ok for the inspection report






Remark for On Duty [Cross Border]

→ When you choose Crossing Border, we must choose a cycle






Type your current location and odometer as per the vehicle and press ok






Inspection Reports List Page

→ Press plus button for vehicle inspection and then select your region as per the country






If there are any issues in the vehicle tick the options in the form and enter remarks if any and press okay






Enter remarks if any defect found






In remarks there are optional fields if required please type in the remarks






- A. Click on e-Sign
- B. Take a picture of any defect
- C. Upload the inspection






if there is no signature added before then add signature by press edit button below





Draw e-Signature






Save & Finish, Save & Confirm or You can add new signature




Logbook


→ Click on Logbook and then it will show the graph




Logbook Graph



Click on Logs then it will show the detail log




Add new logs by click plus button and can also edit or delete existing logs






Add New Logs





Violations






Driver Profile

02:10 🖾 ቆ 📳 •	△ •	ان ﷺ ان 45
Mar Driver Profile		
ID		demodriver03
Carrier Name		DOT Logistics
Carrier ID		4545454
Home Base		Yard
Time Zone		Mountain
License State		AB
License Number		WE1256FG
Operating Mode		ELD
Rule Set	Canada, 70 Hours/7 Days	•
Distance/Volume	Km/Liters	•
Starting 24h time		Midnight
		☐ Exemption



Select the current cycle as per the region






Annotations

03:15 ፟ * ₺ •	∆ 🕸 🗣 🛜	וו. ∯ ווו. 85%
M Annotations		
Annota	tion	
Post-TI		
Annota	tion	
Post-TI		
Annota	tion	
Loading		
Annota	tion	
Loading		
Annota	tion	
Loading		
Annota	tion	
Hooking		
Annota	tion	
Pre-TI		
Annota	tion	
Pre-TI		
Annota	tion	
Unloading		




Certification






Certify Records






Click on Co Driver Login and it will redirect to the login page






Co Driver Login Screen






HOS (Hours of Service)

- → We can switch driver by clicking on driver name
- → We can see below that driving button is disable due to main driver is driving
- → Co-driver can add DVIR by pressing Inspection Reports






Shipment






DOT Inspection





Export ELD Data Option For US





Non-ECM Compliance Compatibility

FLEET HAWKS ELD
is not compatible with
non-ECM powered equipment