
USER GUIDE






B-SOURCE ELD

Driver's Status

Go to the Main Menu and then to Status to view the following data:



Shift:

Displays the remaining hours on your current shift.


Driving Time:

Calculates the remaining driving time for the current shift.

Off-Duty and Breaks:
Displays the required off-duty and break time.

Manage Log

To insert past duty status for any of the past fourteen days:



1. Go to the Main Menu and tap on Logs.
2. Choose a date for the log.
3. Tap on the plus icon and input the log data.
4. Tap Save and the past duty status will be inserted.

* driving time cannot be modified