



User Manual


ELD Connection Setup



First Step

Select your ELD device.


Choose your ELD from the list of available devices, each showing its signal strength.



Second Step

Your ELD is now connected.

Select your ELD from the list of available devices, each displaying its signal strength.




Using an ELD while driving.



Automated tracking of driving time.

Your driving time is automatically recorded when your ELD is connected. When you reach speeds of 5 mph or more, your status changes to "Driving." If you drop below 5 mph and remain stationary for 6 minutes, it switches to "On Duty."




Using an ELD while driving.



First Step

Updating Your Duty Status.


To change your duty status, tap the bar showing your current status on the dashboard. Choose from Off Duty, Sleeper, On Duty, Yard Move, or Personal based on your situation.



Second Step

Entering Trip Details.

Enter your trailer, shipping documents, location, and notes. Use quick select buttons for common notes like "PTI" or "Delivery," or enter them manually. If you leave the location blank, it will be filled automatically.



Follow the guidelines when presenting your documents to the officer.


Using an ELD while driving.



First Step

Use these instructions to show your records to the officer.


Select "Inspection" from the dashboard or menu.



Second Step

Starting a Roadside Inspection.

Next, tap "Begin Inspection" to display your eight-day logbook summary to the officer.



Driver's Daily Log



Displaying your logs.
driving time.

Hand your device to the officer to display your eight-day logbook summary. The screen will show your Driver's Daily Log with all required details.

DRIVER'S DAILY LOG		Sunday, February 5, 2026	
Driver Name	Ferran Tejero	Driver ID	7748962
Driver's License State	USA-HA	Driver's License Number	D00588741322
Co-Driver's Name		Co-Driver ID	
Carrier			
Main Office Location	1116 S Harvey Ave, Oak Park, IL 60304	Home Terminal Location	1116 S Harvey Ave, Oak Park, IL 60304
Driver's Certification Status	No		
Trailers Owned	2017	Shipping Documents	174125
Exempt Driver Status	No, not exempt	Unidentified Driver Records	0 Records
Malfunction Indicators	Yes	Data Diagnostic Indicators	No
Current Location			
Time Zone Offset	PST (UTC-8)	24-Hour Start Time	12:00 AM (Midnight)
ELD Identification Number		ELD Provider Name	


Follow the guidelines when presenting
your documents to the officer.

Send your ELD records to the safety officer for review.



Submitting Your Records.
driving time.

Choose "Web Service" or "Email," add a comment if needed, and press "Confirm" to send your logs to the officer.



Follow the guidelines when presenting your documents to the officer.

395.22 Motor Carrier Responsibilities

Motor carriers must ensure drivers have an ELD information packet onboard that includes malfunction reporting requirements and record-keeping procedures. The following instructions comply with section 395.34.

Malfunction Codes

The ELD monitors and reports malfunctions based on section 4.6 "ELD's Self-Monitoring of Required Functions," table 4.

- P – "Power compliance" malfunction.**
- E – "Engine synchronization compliance" malfunction.**
- T – "Timing compliance" malfunction.**
- L – "Positioning compliance" malfunction.**
- R – "Data recording compliance" malfunction.**
- S – "Data transfer compliance" malfunction.**
- O – "Other" ELD detected malfunction.**