

support@zerooneeld.com ☎ +1 (806) 702-7661


📍 5556 New Territory road, Sugar Land, TX 77479



# User Guide


# ELD Connection Configuration

#1



## 1 Select your ELD device.

Choose your ELD from the list of available devices. Signal strength is shown for each device.




## 2 Your ELD is successfully linked.

A Blue "Connected" status on the dashboard means your ELD is successfully linked and ready to use.

# ELD Connection Configuration

#1




## Automated tracking of driving hours.

Your driving hours are automatically logged when your ELD is connected. When you reach speeds of 5 mph or higher, your status changes to "Driving." If you drop below 5 mph and stay stationary for 6 minutes, it switches to "On Duty."


# Using an ELD while on the road.

#3



## 1 Updating Your Duty Status.

To modify your duty status, tap the bar displaying your current status on the dashboard. Choose from Off Duty, Sleeper, On Duty, Yard Move, or Personal based on your situation.




## 2 Entering Trip Information.

Input your trailer, shipping documents, location, and notes. Use quick select buttons for common notes like "PTI" or "Delivery," or enter them manually. If you leave the location empty, it will be filled automatically.

Ensure you follow the guidelines when presenting your documents to the officer.


# Using an ELD while on the road.

#4



**1 Use these instructions to present your records to the officer.**

Select "Inspection" from the dashboard or menu.



**2 Initiating a Roadside Inspection.**

Next, tap "Start Inspection" to show your eight-day logbook summary to the officer.

# Driver's Daily Log

#5

DRIVER'S DAILY LOG



— DRIVE SMART COMPLIANT —

Sunday, February 17, 2026

USA property 70 hour / 2 days

|                               |                                     |                             |                                     |
|-------------------------------|-------------------------------------|-----------------------------|-------------------------------------|
| Driver Name                   | Joan Cedillo                        | Driver ID                   | 7455122                             |
| Driver's License State        | Texas, USA                          | Driver's License Number     | D1258877822                         |
| Co-Driver's Name              |                                     | Co-Driver ID                |                                     |
| Carrier                       |                                     |                             |                                     |
| Main Office Location          | 27725 Norfolk St, Livonia, MI 48152 | Home Terminal Location      | 27725 Norfolk St, Livonia, MI 48152 |
| Driver's Certification Status | No                                  |                             |                                     |
| Trailers Owned                | 2017                                | Shipping Documents          | 20158                               |
| Exempt Driver Status          | No, not exempt                      | Unidentified Driver Records | 0 Records                           |
| Malfunction Indicators        | Yes                                 | Data Diagnostic Indicators  | No                                  |
| Current Location              |                                     |                             |                                     |
| Time Zone Offset              | PST (UTC-8)                         | 24-Hour Start Time          | 12:00 AM (Midnight)                 |
| ELD Identification Number     |                                     | ELD Provider Name           |                                     |


## Showing your logs and driving hours.

Hand your device to the officer to display your eight-day logbook summary. The screen will present your Driver's Daily Log with all necessary details.

Ensure you follow the guidelines when presenting your documents to the officer.

**Send your ELD records to the safety officer for evaluation.**

**#6**



## **Submitting Your Records.driving time.**

Choose "Web Service" or "Email," add a comment if necessary, and press "Confirm" to send your logs to the officer.

Ensure you follow the guidelines when presenting your documents to the officer.

## 395.22 Motor Carrier Duties

Motor carriers must ensure drivers have an ELD information packet onboard that includes malfunction reporting requirements and record-keeping procedures. The following instructions comply with section 395.34.

## Malfunction Codes

The ELD monitors and reports malfunctions based on section 4.6 "ELD's Self-Monitoring of Required Functions," table 4.

**P – "Power compliance" malfunction.**

**E – "Engine synchronization compliance" malfunction.**

**T – "Timing compliance" malfunction.**

**L – "Positioning compliance" malfunction.**

**R – "Data recording compliance" malfunction.**

**S – "Data transfer compliance" malfunction.**

**O – "Other" ELD detected malfunction.**



💬 [support@zerooneeld.com](mailto:support@zerooneeld.com) ☎ +1 (806) 702-7661

📍 5556 New Territory road, Sugar Land, TX 77479