



User Manual

ELD Connection Setup

1. Select your ELD device.

Choose your ELD from the list of available devices, each showing its signal strength.



2. Your ELD is now connected.


A green "Connected" light on the dashboard indicates that your ELD is successfully linked and ready for use.

Using the ELD while driving.

Application Manual

Automated tracking of driving time.



Your driving time is automatically recorded when your ELD is connected. When you reach speeds of 5 mph or more, your status changes to "Driving." If you drop below 5 mph, it will switch to "On Duty" after being stationary for 6 minutes.



Using an ELD while driving.

1. Updating Your Duty Status.

To change your duty status, tap the bar showing your current status on the dashboard. Select from Off Duty, Sleeper, On Duty, Yard Move, or Personal based on your situation.



2. Entering Trip Details.



Input your Trailer, Shipping Documents, Location, and Notes. You can use quick select buttons for common notes like "PTI" or "Delivery," or enter them manually. If you leave the location blank, it will be filled in automatically.

Review your ELD logs.

Application Manual

1. Use these instructions to present your records to the officer.

Select "Inspection" from the dashboard or menu.



2. Starting a Roadside Inspection.

Next, tap "Begin Roadside Inspection" to show your eight-day logbook summary to the officer.

Make sure to follow the guidelines when presenting your documents to the officer.

Driver's Daily Log.

Application Manual.

DRIVER'S DAILY LOG

Sunday, June 8, 2026

USA property 70 hour / 6 day



Driver Name	Jose Carlos Capitán	Driver ID	8974112
Driver's License State	USA	Driver's License Number	D1258877822
Co-Driver's Name		Co-Driver ID	
Carrier			
Main Office Location	3081 Rose Avenue, New Orleans 70127	Home Terminal Location	3081 Rose Avenue, New Orleans 70127
Driver's Certification Status	No		
Trailers Owned	2016	Shipping Documents	81777
Exempt Driver Status	No, not exempt	Unidentified Driver Records	0 Records
Malfunction Indicators	Yes	Data Diagnostic Indicators	No
Current Location			
Time Zone Offset	PST (UTC-8)	24-Hour Start Time	12:00 AM (Midnight)
ELD Identification Number		ELD Provider Name	


Displaying your logs.

Hand your device to the officer to show your eight-day logbook summary. The screen will display your Driver's Daily Log with all required details.

Make sure to follow the guidelines when presenting your documents to the officer.

Submit your ELD records to the assigned safety officer for review.

Application Manual.

A screenshot of a software interface showing a dialog box titled "Transfer Logs via." The dialog box is white with rounded corners and is centered on a blurred background of a computer screen. Inside the dialog box, there is a section labeled "Comments." with two radio button options: "Web Service." and "Email." Below these options is a text input field labeled "Comments." At the bottom of the dialog box, there are two buttons: "Cancel." and "Confirm." The "Confirm." button is highlighted in dark blue.

Submitting Your Records.

Choose "Web Service" or "Email," add a comment if needed, and press "Confirm" to send your logs to the officer.

Make sure to follow the guidelines when presenting your documents to the officer.

ELD Malfunctions.

Application Manual.

The following instructions are in accordance with the guidelines set forth in 395-34.

ELD will monitor and report malfunction data based on section "4.6 ELD's Self-Monitoring of Required Functions", table 4:

- P – "Power compliance" malfunction,
- E – "Engine synchronization compliance" malfunction,
- T – "Timing compliance" malfunction,
- L – "Positioning compliance" malfunction,
- R – "Data recording compliance" malfunction,
- S – "Data transfer compliance" malfunction,
- O – "Other" ELD detected malfunction.

395.22 Motor Carrier Responsibilities.

A motor carrier must ensure that its drivers possess an ELD information packet onboard a commercial motor vehicle containing the following items: An instruction sheet for the driver describing ELD malfunction reporting requirements and recordkeeping procedures during ELD malfunctions. The following instructions are in accordance with the guidelines set forth in 395-34.



 info@awaeld.com  [+1 \(267\) 532 4485](tel:+12675324485)

 6312 24TH AVE, BROOKLYN, NY, 11204, USA

Thank you for watching!