



ARE YOU ROAD READY?

THE PRIME8 ELD **ROADSIDE INSPECTION**
GUIDE WILL HELP YOU ON YOUR WAY.

PRIME8 ELD

BY GORILLA SAFETY FLEET MANAGEMENT



Online
support@gorillasafety.com
www.gorillasafety.com



Sales Phone Number
Toll Free: 844-636-1360

PRIME8 ELD ROADSIDE INSPECTION GUIDE

1

Welcome Email & Password/Log Into App

2A

Accept/Decline

2B

If Declined/Not Assigned Search for vehicle and assign it.

3

Confirm & Sign

4

Connect ELD to Truck Diagnostic Port

5A

Pair ELD & Confirm Connection

5B

Error? Repeat 4 & 5

1 Choose duty LEFT 10:00
Cycle time left LEFT 8:00

2 Enter remarks Click confirm

3 Confirm location Tap circle to turn on/off YM
Enter Location

4 Confirm location Tap circle to turn on/off PU
Enter Location

Choose Duty Status & Add Remarks
(Selecting Yard Moves and Personal Use, if Applicable)

1 Click to view alerts LEFT 10:00

2 Review alerts Click to go back

View Alerts | *Alerts resolve once action is completed

1 Click to view timer LEFT 9:28

2 Timer tracks remaining hours LEFT 13:28

Timers

1 Click here LEFT 9:28

2 Review hours and miles here

Hours of Service Recap


HOW TO TRANSFER ERODS

1 Click to view logs/docs LEFT 10:00


2 Click icon to view the log/doc you need

3 Click here Enter routing code provided by the authorized safety official.


View DOT Docs & Send ERODS




How to edit log text



How to sign logs



How to edit and save a graph event




Accept unidentified logs/fleet manager edits

How to report malfunctions and recordkeeping procedures

1. Note the malfunction of the ELD and provide written notice of the malfunction to the motor carrier within 24 hours
2. Reconstruct the record of duty status for the current 24-hour period for the current 24-hour period and the previous 7 consecutive days, and record the records of duty status on graph-grid paper logs
3. Continue to manually prepare a record of duty status until the ELD is serviced and brought back into compliance
4. Compliance Malfunction Codes:
 - PWCM – Power
 - ESCM – Engine Synchronization
 - TCM – Timing
 - PCM – Positioning
 - DRCM – Data Recording
 - DTCM Data Transfer
 - O - Other.

DAILY DRIVER'S LOG | One Calendar Day 24/hr

Vehicle #:		MM/DD/YY:	
Trailer #(s):		Day's Total Miles:	
Name of Carrier(s):		Drivers Signature:	
Main Office Address:		Name of Co-Driver:	



Remarks

Shipping Documents #: _____



Get In Touch

844-636-1360




Online

support@gorillasafety.com | www.gorillasafety.com

Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELD ID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT #	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odometer	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	

DAILY DRIVER'S LOG | One Calendar Day 24/hr

Vehicle # :		MM/DD/YY :	
Trailer #(s):		Day's Total Miles:	
Name of Carrier(s):		Drivers Signature:	
Main Office Address:		Name of Co-Driver:	



Remarks

Shipping Documents # : _____




 Get In Touch
844-636-1360

 Online
support@gorillasafety.com | www.gorillasafety.com

Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELD ID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT #	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odometer	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	

DAILY DRIVER'S LOG | One Calendar Day 24/hr

Vehicle #:		MM/DD/YY:	
Trailer #(s):		Day's Total Miles:	
Name of Carrier(s):		Drivers Signature:	
Main Office Address:		Name of Co-Driver:	



Remarks

Shipping Documents #: _____



Get In Touch

844-636-1360




Online

support@gorillasafety.com | www.gorillasafety.com

Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELD ID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT #	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odometer	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	

DAILY DRIVER'S LOG | One Calendar Day 24/hr

Vehicle # :		MM/DD/YY :	
Trailer #(s):		Day's Total Miles:	
Name of Carrier(s):		Drivers Signature:	
Main Office Address:		Name of Co-Driver:	



Remarks

Shipping Documents # : _____




Get In Touch
844-636-1360

Online
support@gorillasafety.com | www.gorillasafety.com

Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELD ID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT #	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odometer	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	

DAILY DRIVER'S LOG | One Calendar Day 24/hr

Vehicle #:		MM/DD/YY:	
Trailer #(s):		Day's Total Miles:	
Name of Carrier(s):		Drivers Signature:	
Main Office Address:		Name of Co-Driver:	



Remarks

Shipping Documents #: _____



Get In Touch

844-636-1360




Online

support@gorillasafety.com | www.gorillasafety.com

Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELD ID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT #	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odometer	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	

DAILY DRIVER'S LOG | One Calendar Day 24/hr

Vehicle # :		MM/DD/YY :	
Trailer #(s):		Day's Total Miles:	
Name of Carrier(s):		Drivers Signature:	
Main Office Address:		Name of Co-Driver:	



Remarks

Shipping Documents # : _____




Get In Touch
844-636-1360

Online
support@gorillasafety.com | www.gorillasafety.com

Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELD ID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT #	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odometer	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	

DAILY DRIVER'S LOG | One Calendar Day 24/hr

Vehicle #:		MM/DD/YY:	
Trailer #(s):		Day's Total Miles:	
Name of Carrier(s):		Drivers Signature:	
Main Office Address:		Name of Co-Driver:	



Remarks

Shipping Documents #: _____



Get In Touch

844-636-1360




Online

support@gorillasafety.com | www.gorillasafety.com

Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELD ID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT #	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odometer	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	

DAILY DRIVER'S LOG | One Calendar Day 24/hr

Vehicle # :		MM/DD/YY :	
Trailer #(s):		Day's Total Miles:	
Name of Carrier(s):		Drivers Signature:	
Main Office Address:		Name of Co-Driver:	



Remarks

Shipping Documents # : _____



 Get In Touch
844-636-1360

 Online
support@gorillasafety.com | www.gorillasafety.com

Drivers License #	
Drivers License State	
Drivers ID	
Co-Driver ID	
ELD ID	
ELD Manufacturer	
ELD Malfunction Indicators	
USDOT #	
Time Zone	
24 Starting Time	
Data Diagnostic Indicators	
Start/End Odometer	
Start/End Engine Hours	
Print/Display Date	
Truck Tractor VIN	
Exempt Driver Status	
Unidentified Driver Records	
Current Location	
File Comment	
Time Zone Offset from UTC	