



ROUTE ONE ELD APP




Download the Route One ELD application



- 1 Search for “Route One ELD” in the Apple store or Google Play store.
- 2 Tap on “Install” button to download the app.
- 3 Wait for the app to be installed on your device.

Sign in to the Route One ELD app

- 1 You need to register an account on routeoneeld.com to use our ELD app.
- 2 After the application is installed, please allow the app to use your location. If you don't accept, the app will be constantly requesting access.




- 3 Log into the application using Username and Password that your carrier has set up for you. Please contact your fleet manager if you don't have an Route One ELD account.
- 4 Select your vehicle from the list. If your vehicle ID is not listed, please contact your fleet manager. Without choosing a vehicle you can not process further.
- 5 Your cellular device will connect to the ELD system automatically. The Bluetooth connection status will be shown at the top of the main screen.

The status will appear in 3 ways:


Disconnected

Disconnected -Bluetooth is disconnected from the device




Searching

Searching - the device is searching ELD and trying to connect



Connected


Connected - the device is connected



Install ELD in your vehicle

- 1 In order to connect the ELD device to the app, please make sure that your truck engine is ON.
- 2 Locate the diagnostic port inside your vehicle's cabin. The diagnostic port is typically located in one of the following places:

- a. Under the left side of the Dashboard
- b. Under the steering wheel
- c. Near the driver's seat
- d. Under the driver's seat




- 3 Plug the device into the diagnostic port of your vehicle and twist the plug base until it locks into place.



- 4 Once plugged in, the device will start syncing with the engine control module (ECM) and Route One ELD application on your device. The ELD device has LED lights to simply indicate its status to the driver.
- 5 The connection will be established automatically in the Route One ELD app. However, if your phone/tablet prompts you or asks for permission to turn on Bluetooth, you need to do that since Bluetooth is needed for the device to communicate with the app.
- 6 From this point on, the device will have and retain the information it needs, such as VIN, to communicate with the app via Bluetooth. Note that for power management reasons, sometimes the LEDs will not stay on.

IOSIX DEVICE



- ✓ **Blinking green and blue**
The app is connected and the Adapter is receiving ECM data.
- ✗ **No light**
Device is not plugged into the truck's diagnostic port.


PT30 DEVICE



- **Flashing green LED** - Device is powered
- **Flashing red LED** - Internal GPS is in acquisition mode.
- **Solid red LED** - The signal is locked, but you CAN proceed to the next step without waiting for GPS lock. Go to the next step.

USING ROUTE ONE ELD OFF THE ROAD

⋮ Route One ELD application offers 3 statuses to choose from:




Personal Conveyance - Off Duty and **Yard Move-On Duty** statuses are available, however must be configured and allowed by a fleet manager.




Press on the status of your choice and set location, add notes (e.g: “PTI”, “Break”, “Shower”) and edit load info if needed.

If your device is connected to the internet, your location will be set automatically, otherwise you should fill out the location field.



USING THE DAILY LOG LIST

Or each day separately



Sign in the field "Certify your events"

The 'Certify your events' screen features a signature field with a handwritten signature. Below the signature field is a certification statement: "I hereby certify that my date entries and my record of duty status for this 24 hour period are true and correct." Two buttons are visible: "Clear" and "Sign".

I hereby certify that my date entries and my record of duty status for this 24 hour period are true and correct.

Clear



Sign



To edit the signature, tap on the "Clear" button and draw your signature again.

DRIVER'S PROFILE SECTION

⋮ In **Profile** section you can change Co-Driver and select/unselect up to 3 Trailers




 **NOTE:**

Other information can be changed through your Fleet Manager only.

HOW TO SEND THE OUTPUT FILE

Tap on the **Inspection** mode in the navigation bar



Tap on **Send output file to FMCSA** button. The application will generate the report for the officer.

Tap on **Send output file via Email** button to send your ELD output file to the DOT via email service.

A respective pop up will appear once ELD file is generated and sent to FMCSA.

You can also **Download PDF** report for the last 8 days.

