



Instruction Manual for Drivers




Table of Contents

Installation & Recording Driving Time

1. Download the Zerion ELD App
2. Login to the Zerion ELD App
3. Connect your mobile device to the Zerion ELD device
4. Record Hours of Service with the Zerion ELD device
5. Let an officer inspect your logs

Troubleshooting


6. Trouble connecting with the ELD device
7. ELD device malfunction

Download Zerion ELD app

STEP 1:

For Android phones and tablets, download the Zerion ELD App from the Google Play Store.


For iPhones and iPads, download the Zerion ELD App from the App Store.



Login to the Zerion ELD app

STEP 2:


Open the Zerion ELD App, enter your username / password. If you don't have a Zerion ELD driver account, contact your fleet manager.



Connect your mobile device to the Zerion ELD


STEP 1:

When you login to your account you will be asked to choose your vehicle from your fleet.




STEP 2:

After you choose your vehicle you will be asked to connect your app to the Zerion ELD device.



STEP 3:


Check if your connection was successful or failed by the icon at the top right corner.



Record Hours of Service with the Zerion ELD

STEP 1:

When your vehicle is moving at 5 MPH or greater, Zerion ELD considers the vehicle to be IN MOTION and your duty status will automatically be set to Driving.




STEP 2:

At 0 MPH, the vehicle is considered to be STATIONARY.


STEP 3:

When STATIONARY, you can change your duty status by tapping DRIVING and selecting one of the alternate duty statuses listed.



STEP 4:

If the vehicle remains STATIONARY for five minutes, a pop-up window will appear that asks if you are still driving or not. If nothing is selected, your duty status will automatically be changed to On Duty.



DOT Inspection mode

STEP 1:

Tap on the DOT icon from the menu.



STEP 2:

To let an officer inspect your logs directly from your device, tap Begin Inspection.

Dot Inspection

START INSPECTION

Select 'Start Inspection' and give your device to the officer

START INSPECTION

SEND LOGS

Send your logs to the officer if they request

SEND LOGS

STEP 3:

To send your ELD output file to the DOT via email or web service, tap Send Output File.

Dot Inspection

START INSPECTION

Select 'Start Inspection' and give your device to the officer

START INSPECTION

SEND LOGS

Send your logs to the officer if they request

SEND LOGS

Trouble connecting with the ELD

STEP 1:

Press on the disconnected icon at the top right corner and try to reconnect.



STEP 2:

Try to turn off your Bluetooth, wait 30 seconds and turn it back on. After you turn it on, go back to the Zerion ELD app and try to reconnect.

STEP 3:

Contact the customer support team and explain the situation and they will test your device and tell you if it is functioning correctly or malfunctioning.

Email: support@zerioneld.com

Web: www.zerioneld.com

ELD Malfunction

§ 395.22 Motor carrier responsibilities—In general.
(h) In-vehicle information. A motor carrier must ensure that its drivers possess onboard a commercial motor vehicle an ELD information packet containing the following items: 3. An instruction sheet for the driver describing ELD malfunction reporting requirements and record keeping procedures during ELD malfunctions. The following instructions are in accordance with the guidelines set forth in § 395.34:

How does the driver know if the ELD is malfunctioning?

Neither of the LED lights on the device are turned on (neither green nor red) when the device is plugged into the truck's diagnostic port and power is flowing to it.

